

COOKS
professional



Bread Bin

Product Code: K828 • K829 • K830 • K831 • K832 • K833 • K834 • K835

After Sales Support
care@cooksprofessional.co.uk

For correct usage, please read these instructions carefully before use and keep in a safe place for future reference.

REGISTER NOW FOR EXTENDED 2-YEAR WARRANTY

When you buy direct from the Cooks Professional website your free 2-year warranty is automatically applied upon purchase (no further action required). If you purchased your product through a different retailer website you can register your product for an extended 2-year warranty by visiting www.cooksprofessional.co.uk/extended-warranty or scan the QR code.



GUARANTEE

Please do not return this product without first emailing our Customer Services at:

care@cooksprofessional.co.uk

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase.

This guarantee does not affect your statutory rights. If your product fails due to a defect in material or workmanship during this period, please return it to the place of purchase. Normal wear and tear is not covered under the guarantee. Any guarantee is invalid if the product has been misused or subject to neglect or an attempted repair other than by our own service centre. Due to continuous product improvement, we reserve the right to change the product specification without prior notice.

EXTENDED 2 YEAR WARRANTY

WHEN YOU BUY DIRECT FROM THE COOKS PROFESSIONAL WEBSITE YOUR FREE 2 YEAR WARRANTY IS AUTOMATICALLY APPLIED UPON PURCHASE.

If you purchased your product through a different retailer you can register your product for an extended 2-year warranty by visiting our website www.cooksprofessional.co.uk/extended-warranty.

The product must be registered, along with your contact information, within 14 days of purchase.

For full terms and conditions please visit our website.

After Sales Customer Service:

E-mail: care@cooksprofessional.co.uk

Please retain for future reference. Colours and contents may vary.

CARE INSTRUCTIONS:

Tin Containers

- **Regular Maintenance:** Wipe with a damp cloth to remove dust and residue. If needed hand wash and dry immediately to prevent rusting.
- **Avoid Water Exposure:** Do not soak in water or put in the dishwasher as prolonged exposure to moisture may cause rust.

Bamboo Lids

- **Cleaning:** Wipe with a damp cloth and dry immediately. If deeper cleaning is needed hand wash with mild soap and water then dry thoroughly.
- **Oil Treatment:** Occasionally apply food-grade mineral oil or bamboo conditioner to maintain the wood's durability and prevent cracking.
- **Avoid Excess Moisture:** Do not soak in water or place in the dishwasher as this may cause warping or cracking.

General Tips

- Ensure lids and tins are completely dry before sealing to prevent moisture buildup and mould.
- Store in a cool dry place away from direct sunlight to preserve their appearance.
- Avoid using metal utensils that could scratch the interior of the tins.

Also available in these colours:



Black



Grey



Teal



Pink



Blue



Green



Silver



Gold

EU Responsible Person

(EU regulatory contact for authorities only)

eucomply OÜ
Pärnu mnt 139b-14
11317 Tallinn, Estonia

hello@eucompliancepartner.com

+33 757690241



Share your purchase with us on social media and tag
[@cooksprofessional](#) to be featured!



We'd like to know what you think!

We'd be very grateful if you can spare a few minutes to leave us a review.
Please review on the retailer website where you placed your order.

Need help?

Our friendly customer care team work Monday to Friday.
Message us at:

care@cooksprofessional.co.uk



Follow us on Instagram